





## **Mobility TRANS**

## Standard Rear Lift conversion Van Standard Equipment

## **Chassis**

- Ford Transit T150
- 130" Wheelbase
- 8,550# GVWR
- 3.5L V6 Ecoboost
- **Power Mirrors and Locks**
- Deep Tint Windows
- Rear Heat and A/C
- Cruise Control
- And Much More!

## **Conversion Flex Package**

4+2, 6+1, 8

- Braun Century II Lift
- Intermotive Interlock
- (2) Q-Straint QRT-DLX
- Right Hand Assist Pole
- Dual Running Boards
- Safety Kit
- Small Back Up Alarm



